

10/100FX/SX NIC Card and Driver

To install the NIC cards and drivers:

- Insert the CD-ROM labeled “10/100FX/SX NIC Card Drivers” into the site computer’s CD drive.
- Locate and open the folder labeled “INSTALL~1”.
- In the folder labeled “INSTALL~1”, locate the 10/100FX/SX NIC Card user’s guide in three formats: Adobe™ Acrobat (INSTALL~1.PDF), Microsoft® Word (INSTALL~1.DOC), and text (INSTALL~1.TXT).
- Open and print a copy of the user’s guide.

Supported system configurations:

- Microsoft Windows® 95/98
- Microsoft Windows NT® 4.0 (x86)
- Novell® NetWare® 4.x/5.x
- Sun® Solaris® (x86)
- DMI Version 2.0
- Linux®

WARNING

Power off the site computer before installing the 10/100FX/SX NIC Card. Failure to observe this warning could result in personal injury and/or death.

- Referring to the printed user’s guide, install the 10/100FX/SX NIC Card.
- Power on the site computer.
- In the 10/100FX/SX NIC Card Drivers CD, locate and open the README.TXT file in the folder containing site drivers.
- Referring to the README.TXT file and to the printed user’s guide, install the 10/100FX/SX NIC Card software driver.

Any trademarks mentioned in this manual are acknowledged to be the property of the trademark owners.