


## Installation Note



AOC's are Uni-Directional cables, with the connectors labeled Source and Display. When connecting, make sure to connect the Source connector to the Source side, and the Display to the Display.



1.877.877.2269



BLACKBOX.COM